

MONTAGEANLEITUNG H4A-INFRAROTHEIZUNG

Überprüfen Sie das mitgelieferte Montageset. Das Montageset besteht aus:

- 2 Wandhalterungen
- 8 Schrauben
- 8 Dübel

SCHRITT 1:

Prüfen Sie, ob die mitgelieferten Dübel und Schrauben für Ihre Wand oder Decke geeignet sind. Für die Montage der Heizung übernimmt Heat4All® keine Haftung. Für Folgeschäden, die auf die Montage zurückzuführen sind, übernimmt Heat4All® ebenfalls keine Gewährleistung. Für Schäden, die auf die Montage ohne die originale Aufhängevorrichtung zurückzuführen sind, wird die Gewährleistung ausgeschlossen und keine Haftung für Folgeschäden übernommen.

SCHRITT 2:

Markieren Sie die acht Bohrlöcher an der vorgesehenen Montagestelle Ihrer Infrarotheizung. Verwenden Sie dafür eine Wasserwaage.

SCHRITT 3:

Bohren Sie an den markierten Stellen die Löcher und stecken Sie die dafür vorgesehenen Dübel in die Bohrlöcher.

SCHRITT 4:

Befestigen Sie die mitgelieferten Wandhalterungen, indem Sie die Schrauben bis zum Anschlag durch die Schlitze der Wandhalterungen in die Dübel drehen (siehe Bild 1).



Bild 1

SCHRITT 5:

Bevor Sie die Heizung in die Wandhalterung einhängen, überprüfen Sie, ob die auf der Rückseite der Heizungen befestigten Abstandhalter bis zum Anschlag eingedreht sind.



Bild 2

SCHRITT 6:

Hängen Sie die Infrarotheizung jetzt in die beiden Wandhalterungen ein (siehe Bild 2).

SCHRITT 7:

Drehen Sie die Abstandhalter so weit heraus, bis die Infrarotheizung einen sicheren Sitz hat. Achten Sie bitte darauf, dass alle vier Abstandhalter gleichmäßig herausgedreht werden.

SCHRITT 8:

Überprüfen Sie, dass die Heizung nicht mehr von der Wand genommen werden kann.

DEMONTAGE:

Drehen Sie die Abstandhalter so weit hinein, dass die Infrarotheizung wieder herausgenommen und abgehängt werden kann.



INSTALLATION MANUAL

H4A-INFRARED HEATING

Please check the enclosed assembling kit. The assembling kit consists of:

- 2 wall holders
- 8 screws
- 8 wall plugs

STEP 1:

Please check whether the enclosed dowels and screws are suitable for your wall or ceiling. Heat4All® does not assume any liability for the installation of the heater. Furthermore, Heat4All® does not assume any warranty for any consequential damages related to the installation of the panel. Heat4All® cannot accept responsibility for damage, loss or injury caused by, or resulting from incorrectly installed equipment.

STEP 2:

Mark the eight drilling holes on the intended installation site. Use a water-level.

STEP 3:

Drill on the marked places the holes into the wall and put the wall plugs into the drilling holes.

STEP 4:

To fix the included wall holders, turn the screws as far as possible through the grooves of the wall holders into the wall plugs (see picture 1).



Picture 1

STEP 5:

Before placing the infrared heater into the wall holders, please check that the four distance pieces on the backside of the heater are screwed in as far as possible.

STEP 6:

Now fit the the infrared heater into the two wall holders (see picture 2).



Picture 2

STEP 7:

Unscrew the four distance pieces so that the infrared heater is fixed to the wall and cannot be removed. Please consider that all four distance pieces are equally unscrewed.

STEP 8:

Make sure that the infrared heater cannot be taken from the wall anymore.

REMOVAL:

Screw in the four distance pieces so that the infared heater can be hung out and taken from the wall.

